

SHAMPY

st^{yję}

0281002445 DRV Control Valve Technical File

Strand Strand Strand Strand Strand Strand Strand Strand	Strand	States .	3) ^{2,22} 3	ġć,
1. 0281002445 DRV Control Valve Introduction				.2
1.1. 0281002445 DRV Control Valve Basic Information				.2
1.2. 0281002445 DRV Control Valve Common Part Number	30.		201 - 304 201	2
1.3. 0281002445 DRV Control Valve Parameter				.2
1.4. 0281002445 DRV Control Valve Quality Control	st."	48 ⁹⁰	çê?	2
1.5. 0281002445 DBV Control Valve Customized Service				3
1.6. 0281002445 DRV Control Valve Packing List and Package Size 1.7. 0281002445 DRV Control Valve Warranty Instructions				.3
1.7. 0281002445 DRV Control Valve Warranty Instructions	30.	321	947 - 99	4
1.8. 0281002445 DRV Control Valve Manufacturer				.5
2. 0281002445 DRV Control Valve Technical Support Obtaining Methods				
 3. 0281002445 DRV Control Valve Purchase and Delivery				.5
3.1. 0281002445 DRV Control Valve Purchase Payment Term				5
3.2. 0281002445 DRV Control Valve Main Sales Markets		(a) :	94	5
3.3. 0281002445 DRV Control Valve Declaration Requirements				.5
3.4. 0281002445 DRV Control Valve Shipping Ways	-2 ^{3,000}	3	98 ^{,200}	5
3.5. 0281002445 DRV Control Valve Lead time				.5
3.6. 0281002445 DRV Control Valve Logistics Time for Destination Out of	f China's /	Areas		6
3.7. 0281002445 DRV Control Valve Packing	30.			6
4. 0281002445 DRV Control Valve Storage Standard				.7
	- 10 C C	100 C	100 C	
5. Company Information	an ^{ger}	4. ²⁰	41. ⁹⁰	.8
5. Company Information	an ^{ger}	4. ²⁰	4. ⁶⁰ . 4	.8
 Company Information 5.1. Company Introduction 5.2. Salesmen's Contact Information 	an ^{ger}	4. ²⁰	4. ⁶⁰ . 4	.8
 5. Company Information 5.1. Company Introduction	an ^{ger}	4. ²⁰	4. ⁶⁰ . 4	.8
 Company Information 5.1. Company Introduction 5.2. Salesmen's Contact Information Copyright Statement 	an ^{ger}	4. ²⁰	4. ⁶⁰ . 4	.8
 5. Company Information	an ^{ger}	4. ²⁰	4. ⁶⁰ . 4	.8
 5.1. Company Introduction	SALES	Stant	skon si skonti si skonti si	.8 .9 .9
 5.1. Company Introduction	Student Student Student Student	SALEANT SALEANT SALEANT SALEANT	SALEANT SI SALEANT SI SALEANT SI	8.8 9.9 9
 5.1. Company Introduction	SALDONT SALDONT SALDONT SALDONT SALDONT	SALENT SALENT SALENT SALENT SALENT	29,200, 20 29,200, 1 29,200, 1 20,200, 1 20,20	S 9.9 S
 5.1. Company Introduction	SALDONT SALDONT SALDONT SALDONT SALDONT	SALENT SALENT SALENT SALENT SALENT	214.2007 20 214.2007 20 214.2007 20 214.2007 20 214.2007 20 214.2007 20 214.2007 20 214.2007 20	8.8.9°.9 % % % %

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

0281002445 DRV Control Valve Technical File

1. 0281002445 DRV Control Valve Introduction

$S^{h^{(j)}}$ and the 1.1. 0281002445 DRV Control Valve Basic Information

Title	China Made New 0281002445 DRV Control Valve	Quality
SKU 1	G1L300281002445	China Made New
SKU 2	G1LB10281002445	China Made New
SKU 3	Y1Z20281002445	Original New
SKU 4	W20000B2B002445	Original New
and the second	and a start	a that a that is

1.2. 0281002445 DRV Control Valve Common Part Number

(1) DRV Control Valve Exchange Information

DRV Control Valve Part Number	Car Model	OE Number	OE Number
0281002445	HYUNDAI/KIA	31402 27000	16938
ANT ANT ANT ANT	and and and	THE THE .	and and a

2 (S)^{67,7} (2) DRV Control Valve Application Information

Common Rail Pipe Part Number	Compatible Number	Car Model	Engine Model
0445213004	0445213005	HYUNDAL	Stran. Month, 24
0445213005	0445213004	HYUNDAI	a main a main a
0445214026	0445214039	HYUNDAI	
0445214039	0445214026	HYUNDAI	State D4EA
0445214039	0445214026	KIA	D4EA
0445214039	0445214026	KIA	D4EA

(3) DRV Control Valve Part Number Common Writing

0281002445, 0445213004, 0445213005, 0445214026, 0445214039, 31402 27000, 16938

1.3. 0281002445 DRV Control Valve Parameter

DRV Control Valve Size: 8cm*5 cm *5 cm DRV Control Valve Package Size: 12cm*7cm*7cm

DRV Control Valve Net Weight: 0.28kg

DRV Control Valve Gross Weight: 0.31kg

DRV Control Valve Quality: China Made New DRV Control Valve MOQ: 4 Pieces

1.4. 0281002445 DRV Control Valve Quality Control

(1) DRV Control Valve Testing

All DRV control valve spare parts are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions. 3.90

(2) DRV Control Valve Inspection

The factory inspection of the DRV control valve is undergone full inspection, random inspection, and

Mob/WhatsApp: +86 13410541523 Email:ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

batch inspection three inspections. Different brands of test benches are used to test the same DRV control valve for a total of no less than three times for factory inspection, and the DRV control valve installation testing environment are progressed in dust-free workshop.

1.5. 0281002445 DRV Control Valve Customized Service

(1) DRV Control Valve Customized Service: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, DRV control valve internal packaging, DRV control valve external packaging and labels customized, etc.

 $S^{(0)}$



(2) DRV Control Valve Customized Service Requirements: Customized DRV control valve packages no less than 100 pieces.

Customized DRV control valve engraving no less than 100 pieces.

The purchased of customized DRV control valve are not less than 1000 pieces.

When the customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

A Once the customized DRV control valve is sold, it cannot be returned or exchanged if there is no quality problems.

-6%

1.6. 0281002445 DRV Control Valve Packing List and Package Size

	troi valve spare Parts List	
No.	1	2
SPARATE SPARAE	r stand sta	and at an a second at a second at
Image	T Statement State	and strang strang strang strang
all all	The The second and the S	
Name	DRV Control Valve	VCI Anti-rust Bag
Description	DRV control valve part number: 0281002445	Prevent DRV control valve from rusting
Description No.	DRV control valve part number: 0281002445	Prevent DRV control valve from rusting 5
	2011 2011 2010 2010 2010 2010 2010 2010	
No.	2011 2011 2010 2010 2010 2010 2010 2010	5

(1) DRV Control Valve Spare Parts List

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

Description Protect the unit pump from leakage

Place DRV control valve and DRV control valve accessories

 $S^{\mathbb{N}^{2}}$

Store State

SAUDIA

Minors are forbidden to use the DRV control valve assembly, spare parts, package box, anti-rust bag

A The protective cover is recyclable accessories that can be reused.

-93^{9,500}

VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

1.7. 0281002445 DRV Control Valve Warranty Instructions

(1) Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the DRV control valve inspection equipment when the DRV control valve is abnormal during use as evidence to feed back to the salesman. Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

(2) DRV Control Valve Warranty Coverage

Within 15 days after customer receives the 0281002445 injector, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 0281002445 DRV control valve has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the DRV control valve is confirmed to be not faulty, it will be returned in its original condition.

A Tips: For products not covered by warranty, our company can provide paid maintenance services. For

products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

(3) DRV Control Valve Out of Warranty Coverage

- The warranty period has expired.
- DRV control valve working failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- DRV control valve damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- DRV control valve working failure or DRV control valve damaged caused by non-DRV control valve design, technology, manufacturing, quality and other issues.
- DRV control valve working failure due to system pressure exceeding system approved pressure.
- DRV control valve working failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- DRV control valve working failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).
- DRV control valve working failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- DRV control valve working failure caused by not following the cleaning requirements specified in the

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

vehicle engine maintenance manual.

18

de Co

• DRV control valve working failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.

1.8. 0281002445 DRV Control Valve Manufacturer

DRV control valve manufacturer: Shenzhen Shumatt Technology Co., Ltd

65

2. 0281002445 DRV Control Valve Technical Support Obtaining Methods

65

(1) DRV Control Valve Technical File , visit <u>http://shumatt.com</u> to get the technical file.
 (2) DRV Control Valve Technical Videos

Facebook: Visit <u>https://www.facebook.com/hison.li</u> to get the technical videos, constantly follow can get more information.

YouTube: <u>https://www.youtube.com/channel/UCByvYBx7VjV_mAfxh_Hu-aw</u> to get the technical videos, constantly follow can get more information.

Shumatt: Visit <u>http://shumatt.com</u> to get the technical videos.

(3) DRV Control Valve Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit <u>http://shumatt.com</u> to get the download and installation tutorial

(4) Search The DRV control valve test data through TruckBook Parts EPC APP.

3. 0281002445 DRV Control Valve Purchase and Delivery

3.1. 0281002445 DRV Control Valve Purchase Payment Term

Payment Terms: T/T, PayPal, Alipay, WeChat

Please contact our salesmen for specific payment information.

Stand and the state of the state of the state of the state of

3.2. 0281002445 DRV Control Valve Main Sales Markets

DRV control valve main sales markets: Asia, Europe, North America, South America, Africa etc.

3.3. 0281002445 DRV Control Valve Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. 0281002445 DRV Control Valve Shipping Ways

Destination in China areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations out of China's areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

customers.

3.5. 0281002445 DRV Control Valve Lead time

Lead time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases).

"Pitters "Pitters "Pitters "Pitters "Pitters "Pitters "Pitters "

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

3.6. 0281002445 DRV Control Valve Logistics Time for Destination Out of China's Areas **DHL Logistics Time :**

Country or Region Departure	n of	Hong Kor China	ng,	Other Countries or Regions of Asia	Australia and Zealand	New	Europe	America	Other Countries	
China's Mainlan	ıd	7 Days	45	7 Days	8 Days	8 Days 8 Days 8-12 Day		8-12 Days	s 7-10 Days	
JPS Logistics Tir	ne: C	ountry o	r Reg	gion of Departure:	China's Mainl	and	State -	31.00°	St. St.	-98
Country of Destination		mated al Time	Со	untry of Destination	Estimated Arrival Time	Cou	Intry of Desti	nation	Estimated Arrival Time	
Japan	31	Days	9	State of the state	5-7Days	Str St	Egypt	3.30	5-7 Days	Ş.
Turkey	5-7	Days		Singapore	3 Days		Switzerland	1	5-7 Days	
Bahrain	5-7	Days	ser ,	Latvia	7-10 Days	أليد أ	New Zealan	8°	7-10 Days	
Sri Lanka	5-7	Days		Thailand	3 Days	100	Austria		5-7 Days	100
Romania	5-7	Days	S.	Vietnam	3-5 Days	1	Estonia	5 . 18	5-7 Days	9
Malaysia	3-5	Days	3	Israel	5-7 Days	3.00	Mexico	37	7-10 Days	3
France	- 5-7	Days	25	America	5-7 Days	⊣ Un	ited Arab Em	irates	5-7 Days	ç.
and Italy and Italy	5-7	Days	5	Netherlands	5-7 Days	3 Star	Bengal	- All	7-10 Days	\otimes^{2}
Lebanon	5-7	Days		Philippine	3-5 Days	Υ.	Greece	_	7-10 Days	
South Korea	31	Days	19 C	Spain	5-7 Days	all'	Myanmar	3.9	5-7 Days	al.
Canada	5-7	Days	-	Germany	5-7 Days		Saudi Arabi	a	7-10 Days	
Portugal	5-7	Days	ser.	Australia	5-7 Days	1 1	South Africa	r	7-10 Days	٩.
Denmark	5-7	Days	1	Belgium	5-7 Days	31	Ukraine	37.0	7-10 Days	-94
India	7-10) Days	100	Qatar	7-10 Days	1	Poland	de se	5-7 Days	0
Indonesia	3-5	Days	ġ	Morocco	7-10 Days	SUP	Pakistan	3. 30	7-10 Days	-93
Kuwait	7-10) Days	. 1	<i>A A</i>		r.	-1	-1	1. A. A.	0

The logistics time is for reference only, subjects are according to the actual arrival.

3.7. 0281002445 DRV Control Valve Packing

STREET. **Domestic express packaging:** Usually wrapped in waterproof scotch tape, such as picture No.1. International express packaging: Wrapped with waterproof yellow tape After wrapping the black protective SPATIES. SPRINT - ALEAN film, such as picture No. 2.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 3, also, the products can be packaged according to customers' requirements.

A The packing tray is made of plastic and can be recycled.

🔺 Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly. $\varphi i^{\mu \beta \bar{\beta}}$ 53.500 -sth

Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and

Mob/WhatsApp: +86 13410541523 Email:ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd Tel: +8675523215133 Website : www.shumatt.com

SPHERE

SPASSAST



Pic No. 3

Pallet Shipping: Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

4. 0281002445 DRV Control Valve Storage Standard

(1) Choose a suitable storage place

The warehouse and cargo yard where the DRV control valve is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkalis, salts and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry. $\otimes^{\mathbb{N}^{[j]}}$

18 C

(2) Strict requirements of warehousing

Strict inspections should be carried out when the DRV control valves are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injectors must be protected from damage.

(3) Keep the warehouse dry and preventing moisture

Mob/WhatsApp: +86 13410541523 Email:ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd Tel: +8675523215133 Website : www.shumatt.com 1.000 C

The relative humidity is usually below 70% for the DRV control valves placed in the room, and the corrosion of the DRV control valves is significantly reduced.

DRV control valve s must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

After the DRV control value is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the DRV control value from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

If the DRV control valve package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

It is forbidden to leave the DRV control valve exposed in the air for a long time.

It is forbidden to store acid, alkali, salt and other substances together with the DRV control valve.

The unpacked DRV control valve must be rust-proof during secondary storage.

5. Company Information



HK Telephone: +852-67653519

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd

Telephone: +86-755-23215133

Email: ruby@shumatt.com

Website: www.shumatt.com

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

Shenzhen Office: Exit C, Qiao Touxi Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

♥ Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: <u>1.10.0281002445 DRV Control Valve Warranty Instructions</u>)

No.	Name	WeChat/WhatsApp	Email
1	Ruby	+86-13410541523	ruby@shumatt.com
2	lvy ivy	+86-18025299821	sales@shumatt.com
S1.3 S1	Rebecca	+86-18025349821	sales01@shumatt.com
4	Janny	+86-18028749821	sales02@shumatt.com
5	Sam Sam	+86-13316859821	Sales8@shumatt.com
⁹⁰ 6 ⁹⁰	Natalie	+86- 18938945856	sales15@shumatt.com
7	Ada	+86-1342286353	sales5@shumatt.com
8	Hison Li	+86-18318811871	web@shumatt.com
9	Mecca	+86-18938948618	sales11@shumatt.com
10	Eric	+86 18319033618	sales3@shumatt.com
s ⁿ 11 s	Wayne (Joaquín en español)	+86-13316959821	wayne@shumatt.com
12	Sylvia	+86 18312499884	sales6@shumatt.com
Stow St	Visit http://shumatt.c	om to obtain the latest information	tion of salesmen
	PS: Shumatt's sales	men's emails are all end with @	shumatt.com

5.2. Salesmen's Contact Information

6. Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds or videos, etc.) provided in "0281002445 DRV Control Valve Technical File" belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "0281002445 DRV Control Valve Technical File" in any way. At the same time, any conditions to spread, repost, display the contents of "0281002445 DRV Control Valve Technical File" is should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use "0281002445 DRV Control Valve Technical File" will violate the "Copyright Law

of the People's Republic of China" and other laws and regulations and the provisions of relevant international SPLICE SHIDN SPUDET SARA 39-50⁵ SPREAM SPREAM SALER SALES . conventions. $\wp^{(0)}$ 519-559-57 SPRESS SPERMIT SPERSONT SPREED SPREED STRATT SHADAT Shank SPERM SALEN 8182555 $\otimes t^{(i)}$ SPERIT SPERMENT SPERMENT SPREEDET 512-2017 SPERSON SPARAT SHURDER'S SPREATS SPREAMENT SPATISTIC SPRANT $\leq \lambda^{(0)}$ STR. PORT STRATT SPANNET SPREAMERT SPRETONT SPREEDENT SPREED SPRENET STATIST SPREEDER SPRETONT SPREIME $\leq k^{2}$ SPRINGER SPERMIT STAROATT SPARAFIT SPREEDST SPREAT SPARATT SPAINATT SPANIAT SPRETONT SPACE SPARISH ϕh^{0} SPRIMATI SHEERINT SPARATI SPACEPTT STRUMPTT SPARATI SPANORT STRUTTON SPRINT SPAJONTY SPARATT Statist $\wp_{i}^{(0)}$ SPERMIT SPANSITY SPLEAT SPACEPTI SPACEMENT SPANNET SPREAT SPLEINT SPURST SPREEMENT 5)^{9,0097} SPRINT φ^{0} SPLINST SPUDAT SPLERAT SPLEME SPREEMEN SPRINGING SHUBST SPLIDAT SPLEMI SPEERS $\otimes^{(0)}$ SPUTTON STUDIE STREET SPECTORY SPLEED SHERRY SPREEDIN SPREEDER SPERIO SPLEEN States $\otimes^{(0)}$ SPERMENT REPART SPERMIT STATISTICS SPLEST SPARAT STREET SPACE SPLEIST STREET SPARTIN SPLEIST $\otimes^{(0)}$ SPREMENT SPREAT SPREAT STRATT STRATISTI SPARENT SPREEDENT STREEMEN 578,00577 STRATISTICS SPANIET SPREAT $\phi^{(0)}$ STAINSTI 5122557 SPRINGER SPAIRS . SPAINT SPRINT $\varphi_{i}^{(0)}$ SPREAT SHUDBERS SPIERS SPORT 38³⁹⁹⁶⁵ SPUTT SAUDAT SPARSE SPARORT $\phi_{i}^{(0)}$ 519JPPPT SPLICET SPERMI SPORE SRITTS. $\varphi^{(0)}$ SPRENT SPERME SPERMIT SHAMAT SPLIDATI SPUTAT SPLEIMET SPARAT SAUDIST SPARAT SHERRIT SPREEDET $\otimes^{[0]}$ SPERMIT 514-25555 SPRIMA STRIPPE C REPORT STATIST Street 212-0077 SPATIST SPLEAT SPREAT SPREEDENT SPREAT STREET SPECIMITY. SPADONT STATIST SPATONT SPREEDENT STRUCT SPREAS $\varphi_{i}^{(k)}$. with . and the and^{ar fi} 1000 . 19⁶⁰

Mob/WhatsApp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd